

Installing Tonkin Bamboo Fence Panels Over a Chain Link Fence

Important Notice:

Reading these instructions prior to attempting assembly will simplify the procedure.

Materials Required:

- Pair of Pliers
- 14 – 16 gauge Galvanized Steel Tie Wire



To fasten the bamboo panel to the support system, follow the next set of instructions below:

1. First straighten out any kinks or humps in your chain link fence to get a flat fence.
2. Attach your Tonkin Bamboo panels by simply rolling out the panel flush against the fence. Snip your tie wire into 6-inch pieces.
3. Slip the tie wire around the cane and twist it around the chain link until snug. Cut off the remains if you like. Do this at the top and bottom until the bamboo is secure. That is it!
4. If the ground is moist, raise the bamboo panel off the ground by 1 inch.

